

## 12" DISC SANDER

### **SAFETY**

Avoid placing hands on sanding disc.

Hold small pieces with a jig or clamp.

Wear proper apparel. Do not wear gloves.

Wear eye protection.

Be sure guards are in place.

Never leave the machine running while unattended.

Always disconnect power from source when changing belt or for maintenance purposes.

### **OPERATIONS**

To change the disc, disconnect the power, remove table, pull off old disk, and clean surface.

Install new disk and replace table. Note old disk cannot be reused.

Table has 45 and 90 degree stops. Always check with a square to verify accuracy.

Do not sand metal objects.

Open the blast gate and start the dust collector. Be sure there are no obstructions; then start the sander.

Avoid kickback by sanding in accordance with the directional arrows. Do not sand small pieces that cannot be safely supported.

Only 120 grit disks are provided.

Discs get clogged with sanding dust and should be cleaned with the crepe rubber stick.